



NOTES:

1. SET ROOT TRUNK COLLAR FLUSH TO 1" ABOVE FINISHED GRADE FOR LANDSCAPE AREAS AND PLANTER AREAS. FINISHED GRADE SHALL BE FLUSH WITH TOP OF CURB, FINISHED SIDEWALK, OR AT GRADE IN LANDSCAPE AREAS.
2. CUT AND REMOVE WIRE BASKETS FROM SIDES OF ROOT BALL WITHOUT DEFORMING BALL. CUT OFF AND REMOVE BURLAP AND ROPE FROM TOP HALF OF ROOT BALL. COMPLETELY REMOVE SYNTHETIC ROPE AND NON-Biodegradable BURLAP.
3. TREES SHALL BE INSTALLED:
 - A. 15' FROM STREET LIGHTS
 - B. 5' FROM FIRE HYDRANTS
 - C. 20' FROM INTERSECTIONS
 - D. 5' FROM ALL PUBLIC UTILITIES (i.e. STORM, SEWER, AND WATERLINES, UTILITY METERS, ETC.)
4. ROOT BARRIER SHALL BE PLACED ABUTTING ALL SIDEWALK EDGES, 12" FROM BACK OF CURB, OR 12" FROM IMPERVIOUS SURFACE AND SHALL EXTEND 20 FEET CENTERED WITH THE TREE BASE.



Public Works Standard Drawings

STREET TREE PLANTING IN PLANTER STRIP

SCALE	NTS	
DATE	JAN '23	REV.
ENGR.	DW	DRAWN
DRAWING NO.	530	KAE