



NOTES:

1. SERVICE CLEANOUT TO BE SAME DIAMETER AND MATERIAL AS SERVICE LATERAL.
 - A. 2-WAY CLEANOUT TO BE USED FOR SEWER DEPTHS UP TO 3 FEET DEEP.
 - B. 1-WAY DIRECTIONAL CLEANOUT SWEEPING TOWARD MAINLINE TO BE USED FOR SEWER DEPTHS GREATER THAN 3 FEET UNLESS DIRECTED OTHERWISE BY ENGINEER.
2. USE OLYMPIC FOUNDRY 8"X4" CLEANOUT RING & COVER PART #M1007 OR APPROVED EQUAL.
3. LOCATION:
 - A. WHERE NEW CURB IS BEING INSTALLED OR EXISTING CURB IS PRESENT AND A PLANTER AREA IS OR WILL EXIST BETWEEN CURB AND SIDEWALK, CLEANOUT SHALL BE PLACED 2 FEET BEHIND CURB.
 - B. WHEN A PLANTER AREA DOES NOT EXIST (i.e. CURB TIGHT SIDEWALK), THE CLEANOUT SHALL BE 12 INCHES FROM BACK OF SIDEWALK TO CENTER OF CLEANOUT.
 - C. WHEN NO CURB OR SIDEWALK EXISTS, LOCATE CLEANOUT 1 FOOT INSIDE RIGHT OF WAY LINE OR AS DIRECTED BY THE ENGINEER.
 - D. WHERE CURB EXISTS BUT NO SIDEWALK, CLEANOUT SHALL BE PLACED 2 FEET BEHIND CURB.
4. VIDEO INSPECT ALL LATERALS FROM MAINLINE TO CLEANOUT/ROW LINE, OR FROM CLEANOUT/ROW LINE TO MAINLINE, PER APPLICABLE APWA/ODOT STANDARDS.



SCALE	NTS
DATE JAN '26	REV. 2
ENGR. DW	DRAWN KAE
DRAWING NO.	310-A